PV6


Battery (P100)
15.9 Volts
RD,50.0,280
C4DC02A-1
C4D108A-1
BK,50.0,460
G4D108-1
Junction box-Battery (P147)
LINK 5B
50.0 Amps
BCM1
C4BF01G-1
GY,10.0,4910
L
C4DF01A-1
LINK 1B
250.0 Amps
EJB LH
C4BF01C-1
RD,25.0,4335
P
LINK 4B
40.0 Amps
BCM4
C4BF01H-1
GN,6.0,4895
IGN
LINK 11B
350.0 Amps
DBFB
C4BF01B-1
RD,35.0,620
C4Y124B-1
LINK 12B
400.0 Amps
STARTER EJBRH
C4BF01A-1
RD,50.0,260
Junction box-
Dual battery (P165)
LINK 10DB
40.0 Amps
C4Y124E-1
GY-OG,4.0,5780
C31B-1
C31A-1
GY-OG,4.0,515
V
LINK 9DB
20.0 Amps
C4Y124E-2
RD-BK,2.5,5780
C31B-13
C31A-13
RD-BK,2.5,515
W
Busbar-Under body (K579)
C4BF08A-1
BATT TO BBAR
BBAR TO STARTER WELD POINT
S1BF08B
RD,50.0,1020
C1DC35A-1
RD,35.0,1350
C1DC35C-1
Starter motor (M101)
MOTOR
Junction box-Engine-Right (P171)
(RHS)
FRM01B
70.0 Amps
(500W)
LINK 1ER
COOLING FAN MOTOR
100.0 Amps
(850W)
C1BB02M-1
RD,16.0,680
G
R287
Relay-Charge air coolant pump (R287)
C1BB02A-33
BN,0.5,1335
C
C1BB02L-1
FUSE 2ER
15.0 Amps
C1BB02A-34
GN-WH,1.0,825
C11M-1
C11L-1
25.0 Amps
MICRO
SSC
GY-YE,0.75,435
C1BB02A-31
GN-WH,1.0,1045
Pump-Coolant-
Charge air (M330)
C1E318-2
PWR
GND
C1E318-1
BK-VT,1.0,1045
C11L-2
C11M-2
BK-VT,1.0,2080
G1D132D-1


Junction box-Engine-Left (P170)
(LHS)
Starter motor (M101)
MOTOR
SOLENOID
PINION
Earth via-fixings (E110)
Engine control module (ECM) (D131)
Gearshift mechanism (D308)
PN SIGNAL
Relay-Starter pinion (R304)
Relay-Starter motor (R291)
Relay-Engine control-module (ECM) (R116)
FUSE 4EL
5.0 Amps
LINK 3EL
40.0 Amps
FUSE 17EL
5.0 Amps
LINK 1EL
40.0 Amps
not connected (V101)
PEMS VVT
PEMS SENSORS
PEMS ACTUATORS
PEMS THROTTLE
PEMS HEGO
PEMS MAF
Not used (V101)
PEMS MID BRICK HEGOS
COILS
C1BB01A-37 GY-BN,2.5,510
S1BB93 GY-BN,2.5,655
C11N-9 C11P-9 OG-GN,2.5,1510
C1DC71A-1 C1DC71B-1 OG-GN,1.5,110
C1DC99B-1
C1BB01A-1 GY-BN,2.5,510
GY-BN,2.5,655
C11N-34 C11P-34 OG-BU,2.5,1510
C1DC71A-2
C1DC71D-2 OG-BU,2.5,110
C1DC99D-1
C1DC71B-2 OG-BU,1.5,110
C1DC99B-2
C1BB01A-55 VT-OG,2.5,320
C1BB01A-52 GY-OG,0.5,260
C1E121B-89
C1BB01A-54 YE,0.5,260
C1E121B-70
C1BB01A-2 VT,0.5,260
C1E121B-14
C1BB01A-40 BN-GN,0.5,260
C1E121B-19
C1BB01A-36 YE,0.5,260
C1E121B-53
C1BB01B-18
C1E121B-86
C1BB01A-22 BN-GN,4.0,560
S1BB91A BN-GN,2.5,645
C1E121B-3
BN-GN,2.5,645
C1E121B-5
BN-GN,2.5,645
C1E121B-6
C1BB01A-30 GY-VT,0.5,260
C1E121B-87
C1BB01A-13 YE-OG,1.0,320
C11N-30 C11P-30 GN,1.0,770
C1BB01A-7 GN-BU,0.5,440
S1BB07 GN-BU,0.5,585
C11N-5 C11P-5 BK-OG,0.5,1930
GN-BU,0.5,220
C1BB01A-9 GY-YE,1.0,1260
S1BB08A GY-YE,0.75,1185
GY-YE,0.75,1405
C11N-11 C11P-11 GY,0.5,1100
C1BB01A-11
GY-YE,1.0,1340
C1BB01B-11 GY-YE,1.0,320
C11N-2 C11P-2 GY,1.0,791
C1BB01B-13 BN,1.0,320
C11N-6 C11P-6 VT,1.0,1370
C1BB01A-5 WH-BU,0.5,610
C1BB01B-7
C1BB01B-9 GY-BN,1.5,660
S1BB13A GY-BN,1.5,805
C11N-37 C11P-37 OG-YE,1.0,1915
GY-BN,1.5,805
C11N-18 C11P-18 OG,1.0,791
C1BB01A-3 YE,2.5,320
C11N-1 C11P-1 WH,2.5,760
C3ET37-6
GN,0.5,440
C33W-22 C33V-22 WH-BN,0.5,1460
C1E121B-17 WH-BN,0.5,605
C31A-19 C31B-19 WH-BN,0.5,1785
S1ET22
C1E121B-1 BK-WH,2.5,475
G1D185A-1
C1E121B-4 BK-WH,2.5,605
G1D185B-1
C1E121B-2 BK-WH,2.5,605
C1E121B-55 BN,0.5,2530
C11X-2 C11W-2 BN,0.5,1335
C
V GY-OG,4.0,515
C1BB01A-51
W RD-BK,2.5,515
C1BB01A-39
GY-RD,2.5,200
C1BB01A-26
N RD,25.0,705
C1BB01L-1
O_S_STRPH
O_S_STRPL
I_S_T50R
O_S_STRTL
O_S_STRTH
V_V_PERMANENT
I_S_TNSW
V_V_BAT_1R
V_V_BAT_2R
V_V_BAT_3R
O_S_MRLY
POWER GND 1
POWER GND 3
POWER GND 2
O_S_CACWPR
E
H
A
K
SYM6
S
B
J
MAF
Y
X
D


Junction box-Central (P101)
C3BP01D-22 GY,10.0,4910
C3BP01D-16 GN,6.0,4895
L
IGN
Relay-Ignition (R211)
Junction box-Central (P101)
Valve-Solenoid-Active exhaust (N173)
GND
BU,1.0,4470
C34N-9 C34P-9
BK,1.0,1260
C4E915-2
Sensor-Position-Accelerator pedal (T113)
C2E901-6 BU-GY,0.5,1560
C2E901-4 BU-WH,0.5,1560
C2E901-5 YE,0.5,1560
C2E901-3 YE-OG,0.5,1560
C2E901-2 VT-GN,0.5,1560
C2E901-1 GN-OG,0.5,1560
Engine control module (ECM) (D131)
C31G-1 C31H-1
BU,1.0,745
C1E121B-56
O_S_EXPL
FUSE 19P
5.0 Amps
C3BP01F-45 BN-WH,0.75,2025
C31F-2 C31E-2
BN-WH,0.5,765
C1E121B-50
I_S_T15
FUSE 14P
5.0 Amps
C3BP01F-41 BN-RD,1.0,1090
C2CA29-4
Switch-Brake pedal (S215)
C3BP01G-6 VT-BN,0.5,1460
S3LS44A
VT-BN,0.5,295
C2CA29-1
VT-BN,0.5,1385
C31D-11 C31C-11
VT-BN,0.5,870
C1E121B-28
I_S_BRKOS
C1E121B-83 GN-OG,0.5,870 C31C-1 C31D-1
O_V_5VAPP1
C1E121B-82 VT-GN,0.5,870 C31C-3 C31D-3
I_A_APP1
C1E121B-81 YE-OG,0.5,870 C31C-2 C31D-2
G_R_APP1
C1E121B-65 YE,0.5,870 C31C-4 C31D-4
I_A_APP2
C1E121B-64 BU-WH,0.5,870 C31C-5 C31D-5
G_R_APP2
C1E121B-66 BU-GY,0.5,870 C31C-6 C31D-6
O_V_5VAPP2
C1E121B-29 VT-WH,0.5,870 C31C-10 C31D-10
I_S_BRKSW
FET-ECM WAKE UP
C3BP01E-19 VT-OG,0.5,2740
C31F-9 C31E-9
VT-OG,0.5,765
C1E121B-49
I_S_WAK
CRANK REQ
C3BP01E-18 BU-WH,0.5,2955
C31B-20 C31A-20
BU-WH,0.35,605
C1E121B-47
I_S_T50
S3CB08 VT-WH,0.5,1330
Restraints Control Module (RCM) (D171)
EVENT NOTIFICATION
I ENS
C3BP01A-21 BN-YE,0.5,2770
S3R113
BN-YE,0.5,235
C3R114B-42
BN-YE,0.5,2895
Switch-Brake pedal (S215)
VT-WH,0.5,540 C2CA29-2
S3D133C BK,0.35,1065 C2CA29-3
BK,0.5,2010
G3D133B-1
FUEL SENS PUMP
C3BP01G-21
BN-YE,0.5,665
C31A-21 C31B-21
FUEL TANK SENDER GND
C3BP01G-8
FUEL SENS EJ
C3BP01G-20
C11N-15 C11P-15
BN-YE,0.5,415
C1E121A-14
I_F_CRASH
F/PUMP RLY LSD
C3BP01E-13
C31B-8 C31A-8
YE-OG,1.0,605
C1E121B-39
O_T_FPMC
C31B-9 C31A-9
BN-WH,1.0,605
C1E121B-48
I_T_FPMD
Module-Fuel-pump driver (D361)
BN-WH,0.75,4145 C4E515-2
YE-OG,0.75,4145 C4E515-5
DIAG O/P
FUEL PUMP POS
PWM CONTROL
FUEL PUMP NEG
PWR
GND
S3D197C SCR,0.5,760
S3D197A
C4E515-6 WH-BN,2.5,760 C34J-6 C34K-6 WH-BN,2.5,275
C4E515-3 YE-GY,2.5,760 C34J-5 C34K-5 YE-GY,2.5,275
BK,1.0,760 C34J-4 C34K-4 SCR,0.5,205 S3D197B BK,0.5,70
C4E515-1
Unit-Fuel Tank (D179)
Pump-Fuel
C4MC11A-3 FUEL PUMP POS
C4MC11A-1 FUEL PUMP NEG
C4MC11A-2 PUMP RTN
C4MC11B-4 ESD GND
C4MC11B-3 FDM LEVEL A
C4MC11B-2 SENDER RTN
C4MC11B-1 FDM LEVEL P
BK,0.5,165
BK,0.5,760
G4D197-1
Junction box-Auxiliary (P148)
FUSE 19B
30.0 Amps
R103
Relay-Fuel-pump (R103)
C3BR01G-5 VT-GN,0.5,2570
C3BR01F-10
BN-WH,2.5,4150 C4E515-4
V-BATT
C3BR01A-1
VBATT TO EJB
C3BR01B-1
YE-VT,0.5,4175 C34J-1 C34K-1 YE-VT,0.5,225
GN-BU,0.75,4175 C34J-3 C34K-3 GN-BU,0.75,225
GN-OG,0.5,4175 C34J-2 C34K-2 GN-OG,0.5,225
N
RD,25.0,705
P
RD,25.0,4335
BK,2.5,760


D
WH,2.5,760
SPL009E
WH,1.0,410
Engine control module (ECM) (D131)
Capacitor (G158)
C1E401-2
BK,1.0,312
G1D1101A-1
C1E401-1
WH,1.0,235
WH,1.0,80
Fuel injector-No.1 (T172)
C1E205-2
C1E205-1
YE-BU,0.75,1510
C1E121A-5
CYL 1 INJ HS
GN-BU,0.75,1510
C1E121A-6
CYL 1 INJ LS
Ignition coil-1 (D233)
SPL011E
C1E303-3
WH,0.5,350
Fuel injector-No.2 (T173)
C1E206-2
C1E206-1
BU-OG,0.75,1410
C1E121A-91
IGT1
C1E121A-51
WH-VT,0.5,1515
C1E303-1
1a
C1E303-2
BK,0.5,145
SPL010E
BK,1.0,310
G1E123-1
INJ HS 2(V6) 5(V8)
GY-YE,0.75,1410
C1E121A-92
INJ LS 2(V6) 5(V8)
Ignition coil-2 (D234)
C1E304-3
WH,0.5,250
Fuel injector-No.3 (T174)
C1E207-2
C1E207-1
GN-VT,0.75,1310
C1E121A-28
IGT2
C1E121A-72
YE-BU,0.5,1415
C1E304-1
2a
C1E304-2
BK,0.5,245
INJ HS 3(V6) 4(V8)
VT,0.75,1310
C1E121A-29
INJ LS 3(V6) 4(V8)
Ignition coil-3 (D235)
C1E305-3
WH,0.5,150
Fuel injector-No.4 (T175)
C1E208-2
C1E208-1
BU,0.75,1470
C1E121A-47
IGT3
C1E121A-52
BU-OG,0.5,1315
C1E305-1
3a
C1E305-2
BK,0.5,345
INJ HS 4(V6) 2(V8)
BANK B -1
YE-OG,0.75,1470
C1E121A-48
INJ LS 4(V6) 2(V8)
Ignition coil-4 (D236)
SPL013E
C1E306-3
WH,0.5,695
Fuel injector-No.5 (T176)
C1E209-2
C1E209-1
WH-GN,0.75,1365
C1E121A-26
INJ HS 5(V6) 6(V8)
IGT 4(V6) 5(V8)
C1E121A-49
GN-VT,0.5,1470
C1E306-1
1b
C1E306-2
BK,0.5,170
SPL012E
BK,1.0,360
G1E124-1
INJ LS 5(V6) 6(V8)
BANK B-2
BN,0.75,1365
C1E121A-27
Ignition coil-5 (D237)
Fuel injector-No.6 (T177)
C1E210-2
C1E210-1
BN-VT,0.75,1265
C1E121A-89
IGT 5(V6) 6(V8)
C1E121A-70
WH-BN,0.5,1365
C1E308-1
C1E308-3
WH,0.5,590
INJ HS 6(V6) 3(V8)
2b
C1E308-2
BK,0.5,275
BANK B-3
GN-WH,0.75,1265
C1E121A-90
INJ LS 6(V6) 3(V8)
Ignition coil-6 (D238)
C1E309-3
WH,0.5,490
Solenoid-VVT-Bank 1-Intake (N196)
SPL014E
GN,0.5,900
C1E421-2
C1E421-1
VT-BN,1.0,1665
C1E121A-23
O_T_CASICA
C1E121A-50
VT-BN,0.5,1265
C1E309-1
3b
C1E309-2
BK,0.5,375
IGT 6(V6) 7(V8)
VVT IN A
Solenoid-VVT-Bank 2-Intake (N198)
GN,0.5,965
C1E422-2
C1E422-1
WH-GN,0.75,1650
C1E121A-31
O_T_CASICB
O_S_ASS
C1E121A-54
GN,0.5,100
C11A-6
C11B-6
GN,0.5,100
C1E316C-2
Valve-Manifold tuning (D312)
VVT IN B
GY,0.5,100
C1E316C-1
Solenoid-VVT-Bank 1-Exhaust (N197)
GN,0.5,975
C1E421A-2
C1E421A-1
VT-GY,1.0,1740
C1E121A-24
O_T_CASECA
C11B-5
C11A-5
GY,0.5,100
SPL015E
GY,0.5,1100
SYM6
VVT EXT A
Solenoid-VVT-Bank 2-Exhaust (N199)
GN,0.5,1125
C1E422A-2
C1E422A-1
WH-OG,0.75,1810
C1E121A-11
O_T_CASECB
GY,0.5,1100
PV6
VVT EXT B
GN,1.0,770
G1D164-1
BK,37.0,345
G1D198-1
ENGINE EARTH BRAID BODY
ENGINE EARTH BRAID
E


Sensor-Heated oxygen-(HO2S)-Front-Right (T182)
UHEGO
A CYL1-3V6
A CYL1-4V8
Sensor-Heated oxygen-(HO2S)-Front-Left (T183)
UHEGO
B CYL4-6V6
B CYL5-8V8
Sensor-Heated oxygen-Post catalyst-Right (T533)
HEGO
A1
A POST
Sensor-Heated oxygen-Post catalyst-Left (T535)
HEGO
B1
B POST
Sensor-Heated oxygen-Mid catalyst-Right (T573)
HEGO
A2
A MID
Sensor-Heated oxygen-Mid catalyst-Left (T572)
HEGO
B2
B MID
Purge control valve (N119)
Motor-Cooling fan-Engine control module (M400)
Engine control module (ECM) (D131)
Throttle-Electric (D249)
Gold Plated
Pump 1-High pressure fuel (M368)
(1st)
Pump 2-High pressure fuel (M369)
(2nd)
Motor-Cooling fan-2 (M103)
PWM
GND
V-BATT
IGN
SPL017E
SPL018E
SPL019E
SPL020E
S1DB04N
S1DB05N
S1BB08C
C11X-1 C11W-1
C11X-8 C11W-8
G1D131E-1
SSC


Sensor-Camshaft position-Bank 1-Intake (T451)
OUT
VREF
GND
C1E706A-3
GN,0.5,1780
C1E121A-13
C1E706A-1
YE-BU,0.5,390
SPL005E
YE-BU,0.5,1390
C1E121A-21
C1E706A-2
GN-VT,0.5,1670
SPL006E
GN-VT,0.5,1340
C1E121A-36
Sensor-Camshaft position-Bank 1-Outlet (T452)
VREF
GND
OUT
C1E736A-1
YE-BU,0.5,285
C1E736A-2
GN-VT,0.5,1565
C1E736A-3
WH-GN,0.5,1675
C1E121A-74
Sensor-Camshaft position-Bank 2-Intake (T453)
(B)
OUT
VREF
GND
C1E707A-3
VT,0.5,1830
C1E121A-34
C1E707A-1
BN-GN,0.5,390
SPL007E
BN-GN,0.5,1440
C1E121A-58
C1E707A-2
BN-BU,0.5,1860
SPL008E
BN-BU,0.5,1480
C1E121A-33
Sensor-Camshaft position-Bank 2-Outlet (T454)
(B)
VREF
GND
OUT
C1E738A-1
BN-GN,0.5,400
C1E738A-2
BN-BU,0.5,1870
C1E738A-3
YE-BU,0.5,1840
C1E121A-53
Sensor-Oil level and temperature (T401)
C1E717A-3
BU-OG,0.5,1925
C1E121A-55
C1E717A-2
WH-VT,0.5,1925
C1E121A-76
C1E717A-1
BK-OG,0.5,1930
H
Engine control module (ECM) (D131)
I_P_CASIA
O_V_5VCASA
G_R_CAS1
I_P_CASEA
I_P_CASIB
O_V_5VCASB
G_R_CAS2
I_P_CASEB
I_T_OCS
G_R_OCS
G_R_ATS
I_A_ATS
I_F_CRS
G_R_CRS
O_V_5VCRS
I_S_KS1A
I_S_KS1B
I_S_KS2A
I_S_KS2B
I_A_IAT1
I_F_AMS1
G_R_AMS1
I_F_AMS2
I_A_IATS2
G_R_DF01
I_F_FQS
NOT USED (V101)
DE711C,SCR,0.5,EN_0G
C1E121A-95
YE-VT,0.5,1675
C1E121A-96
BN-GN,0.5,1675
BN-GN,0.5,838
C1E121A-84
S1E711A
S1E711B
Sensor-Crankshaft-position (CKP) (T102)
Gold Plated
C1E711A-1
C1E711A-2
C1E711A-3
C1E121A-100
WH-BN,0.5,980
C11A-1
C11B-1
WH-BN,0.5,790
C1E801-1
C1E121A-79
VT-OG,0.5,980
C11A-2
C11B-2
VT-OG,0.5,790
C1E801-2
Sensor-Knock-Bank 1 (T443)
(A)
C1E121A-101
BN-GN,0.5,980
C11A-3
C11B-3
BN-GN,0.5,620
VL002-1
C1E121A-80
BN-BU,0.5,980
C11A-4
C11B-4
BN-BU,0.5,620
VL002-2
Sensor-Knock-Bank 2 (T444)
(B)
C1E121B-13
VT-GY,0.5,2530
C11X-7
C11W-7
VT-GY,0.5,1330
C1E807A-4
C1E121B-18
YE-VT,0.5,2530
C11X-6
C11W-6
YE-VT,0.5,1330
C1E807A-5
C1E121B-15
VT-BN,0.5,2530
C11X-5
C11W-5
VT-BN,0.5,1330
C1E807A-1
Sensor-Mass Air Flow and Temperature-(MAFT) Bank 1 (T477)
(1ST-A)
C1E807A-3
C1E121B-52
BU-GY,0.5,2170
C1E807B-5
C1E121B-30
BN-VT,0.5,2170
C1E807B-4
C1E121B-32
VT-BN,0.5,2170
C1E807B-1
Sensor-Mass Air Flow and Temperature-(MAFT) Bank 2 (T478)
(2ND-B)
C1E807B-3
C1E121B-16
GN-BU,0.5,785
C31B-17
C31A-17
GN-BU,0.5,605
C1E121B-12
YE-GN,0.5,785
C31B-15
C31A-15
YE-GN,0.5,605
C1E121B-11
Mirror-Door-Left (M358)
Sensor-Ambient air-temperature (T119)
C3AF-6
C3AE-6
BK,0.5,1235
CAPM26B-9
C3AF-7
C3AE-7
BK,0.5,1235
CAPM26B-8
MAF
WH-BU,0.5,610
S1BB06
WH-BU,0.5,1835
WH-BU,0.5,1475
C11X-11
C11W-11
WH-BU,0.5,1330


Engine control module (ECM) (D131)
Sensor-Manifold Absolute-Pressure (MAP) (T245)
C1E803A-1 GN-WH,0.5,1070 SPL004E GN-WH,0.5,755 C1E121A-15 O_V_5VRAILPS
C1E803A-3 BU-GN,0.5,1825 C1E121A-42 I_A_IMPS
C1E803A-2 BN-GN,0.5,1825 C1E121A-61 G_R_IMPS
Actuator-Bypass valve (N242)
C1E121A-104 GN-VT,0.5,1895 C1E565A-6 O_V_5VCBPP
C1E121A-103 BU-GN,0.5,1895 C1E565A-2 I_A_CBPP
C1E121A-81 YE-GY,0.5,1895 C1E565A-1 G_R_CBPP
C1E121A-64 VT-BN,1.0,1895 C1E565A-3 O_T_CBPPOS
C1E121A-65 GN-VT,1.0,1895 C1E565A-4 O_T_CBPNEG
Sensor-Engine coolant-temperature (ECT) (T121)
C1E716A-1 YE,0.5,1105 C1E121A-38 I_A_ENGTS
Gold Plated
C1E716A-2 WH-BN,0.5,1105 C1E121A-62 G_R_ENGTS
Gold Plated
Sensor-Low fuel-pressure (T280)
C1E121B-85 BN-BU,0.5,870 C31C-7 C31D-7 BN-BU,0.5,4025 C3E830-3 O_V_5VFLPS
C1E121B-35 WH-VT,0.5,870 C31C-9 C31D-9 WH-VT,0.5,4025 C3E830-2 I_A_FLPS
C1E121B-46 GN-WH,0.5,870 C31C-8 C31D-8 GN-WH,0.5,4025 C3E830-1 G_R_FLPS
Sensor-High pressure fuel (T479)
C1E727A-3 GN,0.5,1430 C1E121A-56 G_R_RAILPS
C1E727A-4 BU,0.5,1430 C1E121A-97 I_A_RAILPS
C1E727A-5 GN-WH,0.5,735
C1E727A-2 GN,0.5,1430 C1E121A-41 I_A_FTS
FUEL RAIL TEMP
C1E121B-33 VT-GN,0.5,970 C21B-13 C21A-13 I_S_BRKVAC
VT-GN,0.5,2110
Switch-Brake vacuum (T520)
C21L-7 C21M-7 VT-GN,0.5,2580 C1CA38-1 C1CA38-2 BK,0.75,985 G1D131A-1
Sensor-Radiator outlet-temperature (T300)
C1E759A-1 GN-BN,0.5,2070 C1E121A-37 I_A_RADWTS
Gold Plated
C1E759A-2 WH-VT,0.5,835 SPL016E WH-VT,0.5,1235 C1E121A-12 G_R_SEN
Gold Plated
Sensor-Temperature-Charge air cooler (T593)
(S/C)
C1E843A-1 GY-YE,0.5,2040 C1E121A-40 I_A_CACTS
C1E843A-2 WH-VT,0.5,805
Sensor-Manifold Absolute Pressure-and Temperature(MAPT) (T260)
(S/C)
C1E804-3 BU-GY,0.5,1030 C1E121A-20 O_V_5VBPS
C1E804-4 GN-BN,0.5,1030 C1E121A-82 I_A_BPS
C1E804-1 GY-OG,0.5,1030 C1E121A-63 G_R_BPS
C1E804-2 GY-BU,0.5,1030 C1E121A-17 I_A_BTS
Pump-Diagnostic Module-Tank Leakage (M244)
C1E121B-36 GN-OG,0.5,745 C31H-19 C31G-19 GN-OG,0.35,4445 C4E229-2 O_S_TDMH
C1E121B-21 VT-OG,0.35,870 C31C-16 C31D-16 VT-OG,0.35,4405 C4E229-1 O_S_TDMP
C1E121B-38 BU-GY,0.5,745 C31H-18 C31G-18 BU-GY,0.35,4445 C4E229-3 O_S_TDMV
GN-BU,0.5,220 C31H-20 C31G-20 GN-BU,0.75,4445 C4E229-4
HTR RTN
PUMP RTN
VALVE RTN
PWR
(NAS)
A