PV6


Battery (P100)
RD,50.0,280
C4DC02A-1
15.9 Volts
C4D108A-1
BK,50.0,460
G4D108-1
Junction box-Battery (P147)
LINK 5B
50.0 Amps
BCM1
C4BF01G-1
GY,10.0,4910
L
C4DF01A-1
LINK 1B
250.0 Amps
EJB LH
C4BF01C-1
RD,25.0,4335
P
LINK 4B
40.0 Amps
BCM4
C4BF01H-1
GN,6.0,4895
IGN
LINK 11B
350.0 Amps
DBFB
C4BF01B-1
RD,35.0,620
C4Y124B-1
LINK 12B
400.0 Amps
STARTER EJBRH
C4BF01A-1
RD,50.0,260
Junction box-
Dual battery (P165)
LINK 10DB
40.0 Amps
C4Y124E-1
GY-OG,4.0,5780
C31B-1
C31A-1
GY-OG,4.0,540
V
LINK 9DB
20.0 Amps
C4Y124E-2
RD-BK,2.5,5780
C31B-13
C31A-13
RD-BK,2.5,540
W
Busbar-Under body (K579)
C4BF08A-1
BATT TO BBAR
BBAR TO STARTER WELD POINT
S1BF08B
RD,50.0,1020
C1DC35A-1
RD,35.0,1340
C1DC35C-1
Starter motor (M101)
MOTOR
Junction box-Engine-Right (P171)
(RHS)
FRM01B
70.0 Amps
(500W)
LINK 1ER
100.0 Amps
(850W)
R287
Relay-Charge air
coolant pump (R287)
FUSE 2ER
15.0 Amps
25.0 Amps
MICRO
C1BB02L-1
C1BB02A-31
SSC
GY-YE,0.75,435
C1BB02M-1
RD,16.0,680
G
C1BB02A-33
BN,0.5,1285
C
C1BB02A-34
GN-WH,1.0,825
C11M-1
C11L-1
GN-WH,1.0,1045
Pump-Coolant-
Charge air (M330)
C1E318-2
PWR
GND
C1E318-1
BK-VT,1.0,1045
C11L-2
C11M-2
BK-VT,1.0,2080
G1D132D-1


Junction box-Engine-Left (P170)
V GY-OG,4.0,540
C1BB01A-51
W RD-BK,2.5,540
C1BB01A-39
GY-RD,2.5,100
C1BB01A-26
N RD,25.0,705
C1BB01L-1
VBATT
R304
Relay-Starter pinion (R304)
R291
Relay-Starter motor (R291)
40.0 Amps
MINI
FUSE 4EL
5.0 Amps
LINK 3EL
40.0 Amps
FUSE 17EL
5.0 Amps
LINK 1EL
40.0 Amps
R116
Relay-Engine control-module (ECM) (R116)
70.0 Amps
POWER MINI
FUSE 10EL
PEMS VVT
15.0 Amps
FUSE 7EL
PEMS SENSORS
5.0 Amps
FUSE 9EL
PEMS ACTUATORS
10.0 Amps
FUSE 8EL
PEMS THROTTLE
10.0 Amps
FUSE 12EL
PEMS HEGO
20.0 Amps
FUSE 11EL
PEMS HEGO
20.0 Amps
FUSE 6EL
PEMS MAF
5.0 Amps
V101
Not used (V101)
10.0 Amps
FUSE 13EL
PEMS MID BRICK HEGOS
20.0 Amps
FUSE 5EL
COILS
25.0 Amps
C1BB01A-37 GY-BN,2.5,510
S1BB93 GY-BN,2.5,680
C11N-9 C11P-9 OG-GN,2.5,1510
C1DC71A-1 C1DC71B-1 OG-GN,1.5,110
C1BB01A-1 GY-BN,2.5,510
GY-BN,2.5,680
C11N-34 C11P-34 OG-BU,2.5,1510
C1DC71A-2
C1DC71D-2
C1DC71B-2
C1BB01A-55 VT-OG,2.5,345
C1BB01A-52 GY-OG,0.5,260
C1E121B-89
C1BB01A-54 YE,0.5,260
C1E121B-70
C1BB01A-2 VT,0.5,260
C1E121B-14
C1BB01A-40 BN-GN,0.5,260
C1E121B-19
C1BB01A-36 YE,0.5,260
C1E121B-53
C1BB01B-18
not connected (V101)
C1E121B-86
Engine control module (ECM) (D131)
O_S_STRPH
O_S_STRPL
I_S_T50R
O_S_STRTL
O_S_STRTH
V_V_PERMANENT
not connected (V101)
Starter motor (M101)
C1DC99B-1
MOTOR
OG-BU,2.5,110
C1DC99D-1
SOLENOID
OG-BU,1.5,110
C1DC99B-2
PINION
Earth via-fixings (E110)
Gearshift mechanism (D308)
C3ET37-6
PN SIGNAL
GN,0.5,425
C33W-22 C33V-22 WH-BN,0.5,1460
C1E121B-17 WH-BN,0.5,625
C31A-19 C31B-19 WH-BN,0.5,1785
S1ET22
C1BB01A-22 BN-GN,4.0,560
S1BB91A BN-GN,2.5,645
C1E121B-3
BN-GN,2.5,645
C1E121B-5
BN-GN,2.5,645
C1E121B-6
V_V_BAT_1R
I_S_TNSW
V_V_BAT_2R
V_V_BAT_3R
POWER GND 1
C1E121B-1 BK-WH,2.5,475
G1D185A-1
C1BB01A-30 GY-VT,0.5,260
C1E121B-87
O_S_MRLY
POWER GND 3
C1E121B-4 BK-WH,2.5,605
G1D185B-1
POWER GND 2
C1E121B-2 BK-WH,2.5,605
O_S_CACWPR
C1E121B-55 BN,0.5,2530
C11X-2 C11W-2 BN,0.5,1285
C
C1BB01A-13 YE-OG,1.0,345
C11N-30 C11P-30 GN,1.0,770
E
C1BB01A-7 GN-BU,0.5,440
S1BB07 GN-BU,0.5,610
C11N-5 C11P-5 BK-OG,0.5,1930
H
GN-BU,0.5,220
A
C1BB01A-9 GY-YE,1.0,1260
S1BB08A GY-YE,0.75,1185
K
GY-YE,0.75,1430
C11N-11 C11P-11 GY,0.5,1100
SYM6
C1BB01A-11
not used (V101)
C1BB01B-11 GY-YE,1.0,345
C11N-2 C11P-2 GY,1.0,791
B
C1BB01B-13 BN,1.0,345
C11N-6 C11P-6 VT,1.0,1370
J
C1BB01A-5 WH-BU,0.5,610
MAF
C1BB01B-7
C1BB01B-9 GY-BN,1.5,660
S1BB13A GY-BN,1.5,830
C11N-37 C11P-37 OG-YE,1.0,1915
Y
GY-BN,1.5,830
C11N-18 C11P-18 OG,1.0,791
X
C1BB01A-3 YE,2.5,345
C11N-1 C11P-1 WH,2.5,760
D


Junction box-Central (P101)
C3BP01D-22 GY,10.0,4910
C3BP01D-16 GN,6.0,4895
L
IGN
Relay-Ignition (R211)
Valve-Solenoid-Active exhaust (N173)
GND
Sensor-Position-Accelerator pedal (T113)
C2E901-6 BU-GY,0.5,1560
C2E901-4 BU-WH,0.5,1560
C2E901-5 YE,0.5,1560
C2E901-3 YE-OG,0.5,1560
C2E901-2 VT-GN,0.5,1560
C2E901-1 GN-OG,0.5,1560
BU,1.0,4470
C34N-9 C34P-9 BK,1.0,1260
C4E915-2
Junction box-Central (P101)
Engine control module (ECM) (D131)
C31G-1 C31H-1 BU,1.0,745
C1E121B-56
O_S_EXPL
FUSE 19P
5.0 Amps
C3BP01F-45 BN-WH,0.75,2025
C31F-2 C31E-2 BN-WH,0.5,770
C1E121B-50
I_S_T15
Switch-Brake pedal (S215)
FUSE 14P
5.0 Amps
C3BP01F-41 BN-RD,1.0,1090
C2CA29-4
C3BP01G-6 VT-BN,0.5,1460
S3LS44A VT-BN,0.5,295
C2CA29-1
VT-BN,0.5,1385
C31D-11 C31C-11 VT-BN,0.5,870
C1E121B-28
I_S_BRKOS
O_V_5VAPP1
I_A_APP1
G_R_APP1
I_A_APP2
G_R_APP2
O_V_5VAPP2
I_S_BRKSW
C1E121B-83 GN-OG,0.5,870 C31C-1 C31D-1
C1E121B-82 VT-GN,0.5,870 C31C-3 C31D-3
C1E121B-81 YE-OG,0.5,870 C31C-2 C31D-2
C1E121B-65 YE,0.5,870 C31C-4 C31D-4
C1E121B-64 BU-WH,0.5,870 C31C-5 C31D-5
C1E121B-66 BU-GY,0.5,870 C31C-6 C31D-6
C1E121B-29 VT-WH,0.5,870 C31C-10 C31D-10
FET-ECM-Wake-Up (Z189)
C3BP01E-19 VT-OG,0.5,2740
C31F-9 C31E-9 VT-OG,0.5,770
C1E121B-49
I_S_WAK
CRANK REQ
C3BP01E-18 BU-WH,0.5,2955
C31B-20 C31A-20 BU-WH,0.35,625
C1E121B-47
I_S_T50
S3CB08 VT-WH,0.5,1330
Restraints Control Module (RCM) (D171)
EVENT NOTIFICATION
I ENS
C3BP01A-21 BN-YE,0.5,2770
S3R113 BN-YE,0.5,235
C3R114B-42
BN-YE,0.5,2895
BN-YE,0.5,710
C31A-21 C31B-21
Switch-Brake pedal (S215)
VT-WH,0.5,540 C2CA29-2
S3D133C BK,0.35,1065 C2CA29-3
BK,0.5,2010
G3D133B-1
FUEL SENS PUMP
C3BP01G-21
FUEL TANK SENDER GND
C3BP01G-8
FUEL SENS EJ
C3BP01G-20
F/PUMP RLY LSD
C3BP01E-13
C11N-15 C11P-15 BN-YE,0.5,415
C1E121A-14
I_F_CRASH
C31B-8 C31A-8 YE-OG,1.0,625
C1E121B-39
O_T_FPMC
C31B-9 C31A-9 BN-WH,0.75,625
C1E121B-48
I_T_FPMD
Module-Fuel-pump driver (D361)
BN-WH,0.75,4145 C4E515-2
YE-OG,0.75,4145 C4E515-5
DIAG O/P
FUEL PUMP POS
PWM CONTROL
FUEL PUMP NEG
PWR
GND
C4E515-4
C4E515-6
C4E515-3
C4E515-1
S3D197C SCR,0.5,760
S3D197A BK,0.5,760
WH-BN,2.5,760 C34J-6 C34K-6 WH-BN,2.5,275
YE-GN,2.5,760 C34J-5 C34K-5 YE-GY,2.5,275
BK,1.0,80 C34J-4 C34K-4 SCR,0.5,205
S3D197B BK,0.5,70
BK,0.5,165
Unit-Fuel Tank (D179)
Pump-Fuel
C4MC11A-3 FUEL PUMP POS
C4MC11A-1 FUEL PUMP NEG
C4MC11A-2 PUMP RTN
C4MC11B-4 ESD GND
C4MC11B-3 FDM LEVEL A
C4MC11B-2 SENDER RTN
C4MC11B-1 FDM LEVEL P
Junction box-Auxiliary (P148)
FUSE 19B
30.0 Amps
R103
Relay-Fuel-pump (R103)
C3BR01G-5 VT-GN,0.5,2570
C3BR01F-10 BN-WH,2.5,4120
V-BATT
C3BR01A-1
VBATT TO EJB
C3BR01B-1
N RD,25.0,705
P RD,25.0,4335
YE-VT,0.5,4175 C34J-1 C34K-1 YE-VT,0.5,225
GN-BU,0.75,4175 C34J-3 C34K-3 GN-BU,0.75,225
GN-OG,0.5,4175 C34J-2 C34K-2 GN-OG,0.5,225
G4D197-1
BK,2.5,760


D
WH,2.5,760
SPL009E
WH,1.0,410
Engine control module (ECM) (D131)
Capacitor (G158)
C1E401-2
BK,1.0,312
G1D1101A-1
C1E401-1
WH,1.0,235
WH,1.0,60
Fuel injector-No.1 (T172)
C1E205-2
C1E205-1
YE-BU,0.75,1510
GN-BU,0.75,1510
C1E121A-5
C1E121A-6
CYL 1 INJ HS
CYL 1 INJ LS
Fuel injector-No.2 (T173)
C1E206-2
C1E206-1
BU-OG,0.75,1410
GY-YE,0.75,1410
C1E121A-91
C1E121A-92
INJ HS 2(V6) 5(V8)
INJ LS 2(V6) 5(V8)
Fuel injector-No.3 (T174)
C1E207-2
C1E207-1
GN-VT,0.75,1310
VT,0.75,1310
C1E121A-28
C1E121A-29
INJ HS 3(V6) 4(V8)
INJ LS 3(V6) 4(V8)
Fuel injector-No.4 (T175)
C1E208-2
C1E208-1
BU,0.75,1470
YE-OG,0.75,1470
C1E121A-47
C1E121A-48
INJ HS 4(V6) 2(V8)
INJ LS 4(V6) 2(V8)
Fuel injector-No.5 (T176)
C1E209-2
C1E209-1
WH-GN,0.75,1365
BN,0.75,1365
C1E121A-26
C1E121A-27
INJ HS 5(V6) 6(V8)
IGT 4(V6) 5(V8)
INJ LS 5(V6) 6(V8)
Fuel injector-No.6 (T177)
C1E210-2
C1E210-1
BN-VT,0.75,1265
GN-WH,0.75,1265
C1E121A-89
C1E121A-90
IGT 5(V6) 6(V8)
INJ HS 6(V6) 3(V8)
INJ LS 6(V6) 3(V8)
Solenoid-VVT-Bank 1-Intake (N196)
SPL014E
GN,0.5,900
C1E421-2
C1E421-1
VT-BN,1.0,1665
C1E121A-23
O_T_CASICA
IGT 6(V6) 7(V8)
Solenoid-VVT-Bank 2-Intake (N198)
GN,0.5,965
C1E422-2
C1E422-1
WH-GN,0.75,1650
C1E121A-31
O_T_CASICB
O_S_ASS
Solenoid-VVT-Bank 1-Exhaust (N197)
GN,0.5,975
C1E421A-2
C1E421A-1
VT-GY,1.0,1740
C1E121A-24
O_T_CASECA
Solenoid-VVT-Bank 2-Exhaust (N199)
GN,0.5,1125
C1E422A-2
C1E422A-1
WH-OG,0.75,1810
C1E121A-11
O_T_CASECB
GN,1.0,770
E
G1D164-1
BK,37.0,345
G1D198-1
Ignition coil-1 (D233)
C1E121A-51
WH-VT,0.5,1515
C1E303-1
IGT1
C1E303-3
WH,0.5,350
C1E303-2
BK,0.5,145
SPL011E
SPL010E
BK,1.0,310
G1E123-1
Ignition coil-2 (D234)
C1E121A-72
YE-BU,0.5,1415
C1E304-1
IGT2
C1E304-3
WH,0.5,250
C1E304-2
BK,0.5,245
Ignition coil-3 (D235)
C1E121A-52
BU-OG,0.5,1315
C1E305-1
IGT3
C1E305-3
WH,0.5,150
C1E305-2
BK,0.5,345
Ignition coil-4 (D236)
SPL013E
C1E306-3
WH,0.5,695
C1E121A-49
GN-VT,0.5,1470
C1E306-1
C1E306-2
BK,0.5,170
SPL012E
BK,1.0,360
G1E124-1
Ignition coil-5 (D237)
C1E121A-70
WH-BN,0.5,1365
C1E308-1
C1E308-3
WH,0.5,590
C1E308-2
BK,0.5,275
Ignition coil-6 (D238)
C1E309-3
WH,0.5,490
C1E121A-50
VT-BN,0.5,1265
C1E309-1
C1E309-2
BK,0.5,375
Valve-Manifold tuning (D312)
C1E121A-54
GN,0.5,100
C11A-6
C11B-6
GN,0.5,100
C1E316C-2
GY,0.5,100
C1E316C-1
C11B-5
C11A-5
GY,0.5,100
SPL015E
GY,0.5,1100
SYM6
GY,0.5,1100
PV6


Sensor-Heated oxygen-(HO2S)-Front-Right (T182)
Sensor-Heated oxygen-(HO2S)-Front-Left (T183)
Sensor-Heated oxygen-Post catalyst-Right (T533)
Sensor-Heated oxygen-Post catalyst-Left (T535)
Sensor-Heated oxygen-Mid catalyst-Right (T573)
Sensor-Heated oxygen-Mid catalyst-Left (T572)
Purge control valve (N119)
Engine control module (ECM) (D131)
Throttle-Electric (D249)
Pump 1-High pressure fuel (M368)
Pump 2-High pressure fuel (M369)
Motor-Cooling fan-2 (M103)
PWM
GND
V-BATT
IGN
Gold Plated


Sensor-Camshaft position-Bank 1-Intake (T451)
OUT
VREF
GND
C1E706A-3
GN,0.5,1780
C1E121A-13
C1E706A-1
YE-BU,0.5,390
SPL005E
YE-BU,0.5,1390
C1E121A-21
C1E706A-2
GN-VT,0.5,1670
SPL006E
GN-VT,0.5,1340
C1E121A-36
Sensor-Camshaft position-Bank 1-Outlet (T452)
VREF
GND
OUT
C1E736A-1
YE-BU,0.5,285
C1E736A-2
GN-VT,0.5,1565
C1E736A-3
WH-GN,0.5,1675
C1E121A-74
Sensor-Camshaft position-Bank 2-Intake (T453)
OUT
VREF
GND
C1E707A-3
VT,0.5,1830
C1E121A-34
C1E707A-1
BN-GN,0.5,390
SPL007E
BN-GN,0.5,1440
C1E121A-58
C1E707A-2
BN-BU,0.5,1860
SPL008E
BN-BU,0.5,1480
C1E121A-33
Sensor-Camshaft position-Bank 2-Outlet (T454)
VREF
GND
OUT
C1E738A-1
BN-GN,0.5,400
C1E738A-2
BN-BU,0.5,1870
C1E738A-3
YE-BU,0.5,1840
C1E121A-53
Sensor-Oil level and temperature (T401)
C1E717A-3
BU-OG,0.5,1925
C1E121A-55
C1E717A-2
WH-VT,0.5,1925
C1E121A-76
C1E717A-1
BK-OG,0.5,1930
H
GN-BU,0.5,785
C31B-17
C31A-17
GN-BU,0.5,625
C1E121B-12
YE-GN,0.5,785
C31B-15
C31A-15
YE-GN,0.5,625
C1E121B-11
C3AF-6
C3AE-6
BK,0.5,1275
CAPM26B-9
C3AF-7
C3AE-7
BK,0.5,1275
CAPM26B-8
Engine control module (ECM) (D131)
I_P_CASIA
O_V_5VCASA
G_R_CAS1
I_P_CASEA
I_P_CASIB
O_V_5VCASB
G_R_CAS2
I_P_CASEB
I_T_OCS
G_R_OCS
G_R_ATS
I_A_ATS
I_F_CRS
G_R_CRS
O_V_5VCRS
I_S_KS1A
I_S_KS1B
I_S_KS2A
I_S_KS2B
I_A_IAT1
I_F_AMS1
G_R_AMS1
I_F_AMS2
I_A_IATS2
G_R_DF01
I_F_FQS
NOT USED (V101)
C1E121B-16
Mirror-Door-Left (M358)
Sensor-Ambient air-temperature (T119)
DE711C,SCR,0.5,EN_0G
C1E121A-95
YE-VT,0.5,1675
C1E711A-1
C1E121A-96
BN-GN,0.5,1675
BN-GN,0.5,838
C1E711A-2
C1E121A-84
GY-VT,0.5,838
S1E711A
C1E711A-3
S1E711B
Sensor-Crankshaft-position (CKP) (T102)
Gold Plated
C1E121A-100
WH-BN,0.5,980
C11A-1
C11B-1
WH-BN,0.5,790
C1E801-1
C1E121A-79
VT-OG,0.5,980
C11A-2
C11B-2
VT-OG,0.5,790
C1E801-2
Sensor-Knock-Right bank (T181)
C1E121A-101
BN-GN,0.5,980
C11A-3
C11B-3
BN-GN,0.5,620
VL002-1
C1E121A-80
BN-BU,0.5,980
C11A-4
C11B-4
BN-BU,0.5,620
VL002-2
Sensor-Knock-Left bank (T180)
C1E121B-13
VT-GY,0.5,2530
C11X-7
C11W-7
VT-GY,0.5,1345
C1E807A-4
C1E121B-18
YE-VT,0.5,2530
C11X-6
C11W-6
YE-VT,0.5,1345
C1E807A-5
C1E121B-15
VT-BN,0.5,2530
C11X-5
C11W-5
VT-BN,0.5,1345
C1E807A-1
Silver Plated
Sensor-Mass air-flow (MAF) (T115)
C1E807A-3
C1E121B-52
BU-GY,0.5,2170
C1E807B-5
C1E121B-30
BN-VT,0.5,2170
C1E807B-4
C1E121B-32
VT-BN,0.5,2170
C1E807B-1
Sensor-Mass Air Flow and Temperature-(MAFT) Bank 2 (T478)
C1E807B-3
MAF
WH-BU,0.5,610
S1BB06
WH-BU,0.5,1835
WH-BU,0.5,1475
C11X-11
C11W-11
WH-BU,0.5,1345


Engine control module (ECM) (D131)
Sensor-Manifold Absolute-Pressure (MAP) (T245)
C1E803A-1 GN-WH,0.5,1070 SPL004E GN-WH,0.5,755 C1E121A-15 O_V_5VRAILPS
C1E803A-3 BU-GN,0.5,1825 C1E121A-42 I_A_IMPS
C1E803A-2 BN-GN,0.5,1825 C1E121A-61 G_R_IMPS
Sensor-Engine coolant-temperature (ECT) (T121)
C1E716A-1 YE,0.5,1105 Gold Plated C1E121A-38 I_A_ENGTS
C1E716A-2 WH-BN,0.5,1105 Gold Plated C1E121A-62 G_R_ENGTS
Sensor-High pressure fuel (T479)
C1E727A-3 GN,0.5,1430 C1E121A-56 G_R_RAILPS
C1E727A-4 BU,0.5,1430 C1E121A-97 I_A_RAILPS
C1E727A-5 GN-WH,0.5,735
FUEL RAIL TEMP
C1E727A-2 GN,0.5,1430 C1E121A-41 I_A_FTS
Sensor-Radiator outlet-temperature (T300)
C1E759A-1 GN-BN,0.5,2070 Gold Plated C1E121A-37 I_A_RADWTS
C1E759A-2 WH-VT,0.5,835 Gold Plated SPL016E WH-VT,0.5,1235 C1E121A-12 G_R_SEN
Sensor-Temperature-Charge air cooler (T593)
C1E843A-1 GY-YE,0.5,2040 C1E121A-40 I_A_CACTS
C1E843A-2 WH-VT,0.5,805
Sensor-Manifold Absolute Pressure-and Temperature(MAPT) (T260)
C1E804-3 BU-GY,0.5,1030 C1E121A-20 O_V_5VBPS
C1E804-4 GN-BN,0.5,1030 C1E121A-82 I_A_BPS
C1E804-1 GY-OG,0.5,1030 C1E121A-63 G_R_BPS
C1E804-2 GY-BU,0.5,1030 C1E121A-17 I_A_BTS
Actuator-Bypass valve (N242)
O_V_5VCBPP C1E121A-104 GN-VT,0.5,1895 C1E565A-6
I_A_CBPP C1E121A-103 BU-GN,0.5,1895 C1E565A-2
G_R_CBPP C1E121A-81 YE-GY,0.5,1895 C1E565A-1
O_T_CBPPOS C1E121A-64 VT-BN,1.0,1895 C1E565A-3
O_T_CBPNEG C1E121A-65 GN-VT,1.0,1895 C1E565A-4
Sensor-Low fuel-pressure (T280)
O_V_5VFLPS C1E121B-85 BN-BU,0.5,870 C31C-7 C31D-7 BN-BU,0.5,4025 C3E830-3
I_A_FLPS C1E121B-35 WH-VT,0.5,870 C31C-9 C31D-9 WH-VT,0.5,4025 C3E830-2
G_R_FLPS C1E121B-46 GN-WH,0.5,870 C31C-8 C31D-8 GN-WH,0.5,4025 C3E830-1
I_S_BRKVAC C1E121B-33 VT-GN,0.5,970 C21B-13 C21A-13
VT-GN,0.5,2110
C21L-7 C21M-7 VT-GN,0.5,2580 C1CA38-1
Switch-Brake vacuum (T520)
C1CA38-2 BK,0.75,1000 G1D131B-1
Pump-Diagnostic Module-Tank Leakage (M244)
O_S_TDMH C1E121B-36 GN-OG,0.5,745 C31H-19 C31G-19 GN-OG,0.35,4445 C4E229-2
O_S_TDMP C1E121B-21 VT-OG,0.35,870 C31C-16 C31D-16 VT-OG,0.35,4405 C4E229-1
O_S_TDMV C1E121B-38 BU-GY,0.5,745 C31H-18 C31G-18 BU-GY,0.35,4445 C4E229-3
GN-BU,0.5,220 C31H-20 C31G-20 GN-BU,0.75,4445 C4E229-4
HTR RTN
PUMP RTN
VALVE RTN
PWR
(NAS)
A